

STERN SHAKER MOTOR CONNECTOR INSTALLATION

- With the game powered OFF, remove your shaker motor cable at CN16. These are usually blue and red wires.
- Plug in the female end of the included Pinlights Shaker interface Cable into CN16.
- Plug the shaker motor into the Z connector end of the Pinlights Shaker interface cable.
- Plug the black 2 pin JST connector into your Pinlights flasher Cable harness.

DOUBLE CHECK YOUR CONNECTIONS. MAKE SURE THE 48V LINE AT CN1 (GRAY/BLACK CABLES) STILL HAS THE CAPACITOR CONNECTED (IF PRESENT ORIGINALLY). IF YOU HAVE QUESTIONS, CONTACT SUPPORT@PINLIGHTS.NET

CN16
➔

